




# FIELD & STREAM™

1871

Installation Instructions

## IMPORTANT

- Record the serial number from the tag on the back of the safe or from the tag on the front bottom corner of the safe.
- Keep combination in a secure place away from children. Do not store this document in the safe.
- Do not move this safe using its handle. The handle should only be used for opening and closing the door of the safe.
- Removing the back panel on the door will void the fire rating.

<b>⚠ WARNING</b>	<b>Tip Over Hazard</b>
	<p>A child or adult can tip the safe and be killed or seriously injured.</p> <p>Failure to secure the safe as shown in these instructions can result in death or serious injury to children and adults.</p> <p>Children should not play with or around the safe at any time.</p>

Serial #	Combination #
----------	---------------

## INSTALLATION OF SCOPE STAND-OFF

NOTE: The scope stand-off will function properly for many combinations of guns with scopes.

Screw the scope stand-off into the pilot hole of the barrel rest. (Figure 1)

## SELECTING A LOCATION

Your safe should be installed in an isolated, dry and secure area.

For extra humidity control we recommend the use of a desiccant. Do not drill holes in the safe for electrical dehumidifying devices. This will void the fire rating.

For greater security the safe should be located in a corner and fastened to the floor. (Figure 2)

The safe should be flat against the wall and floor. Remove the baseboard if necessary. (Figure 3)

## SECURING THE SAFE

If you are going to secure your safe to the floor it will first be necessary to drill pilot holes through the fire insulation in the floor of the safe. First place the safe in the desired location. Lift the bottom carpeting up to find the two hole locations marked on the floor insulation. Drill holes through the insulation **using the same diameter drill as the diameter of the mounting hardware you are using**. **IMPORTANT:** The fasteners you use must completely fill the hole you drilled into the insulation. (Figure 4) You must use the fasteners after you drill the holes. Failure to do so will void the fire rating.


Use these holes to fasten the safe to the floor. Drill the appropriate diameter and depth of pilot holes into the floor depending on the type of hardware being used and the type of floor surface. (Figure 3)

Secure the safe with the fasteners and replace the carpeting.

## SHELVING

The shelving can be installed by locating the shelf clips to the desired locations and setting the shelf in place. (Figure 5)

- ★ Do not store electronic media, computer disks, audio-visual media or photographic negatives in this safe. This material will not survive the rated internal temperature of the safe. This material may be damaged or destroyed.



## Combination Number

1st  
3 times (R)

2nd  
2 times (L)


3rd  
1 time (R)

### HOW TO OPEN

All numbers must be dialed exactly. If you pass a number, you can not back up. You must start over. All numbers are to be dialed to the Top Notch located on top of the dial ring (the 12 o'clock position).

1. Turn the Dial clockwise passing the first combination number twice landing on the number the third time.
2. Now turn the Dial counterclockwise, passing the second combination number once landing on the number on the next time around.
3. Turn the Dial clockwise until you reach the third combination number.
4. The handle should now be released. Turn the handle clockwise. Pull the door towards you.

Example: If the dial combination numbers were 70 - 50 - 30



### HOW TO LOCK

1. Close the door.
2. Turn the handle to the locked position.
3. Turn the dial either direction a few rounds.



#### WARNING

Keep your safe closed and locked at all times when not in use. Children could accidentally be locked inside the safe.

### IMPORTANT

Keep your combination number in a secure place, away from children. Keep this record of your serial number and combination number in a secure place separate from your safe. If you forget or lose the combination number you will need the serial number as a reference for obtaining a copy of your combination number.

To obtain a copy of your combination number, follow the instructions on the attached form.



**FIELD & STREAM™**  
1871



**FIELD & STREAM.**  
1871

**Safe Combination Request - This is not a Registration Form**

Verification of ownership is required in order to receive your combination for your safe

**In order to receive a replacement combination to your security product:**

1. Complete the following form and send to Stack-On Products.
2. Send a copy of your valid driver's license along with the form.
3. Send a copy of the receipt showing the original purchase.
4. Security product owner must sign form.
5. Owner's signature must be notarized.
6. Send \$10.00 for combination confirmation. Personal Check, MasterCard, or Visa accepted.
7. Send completed information to: Stack-On Products Company  
1360 N. Old Rand Road  
P.O. box 489  
Wauconda, IL 60084

Serial Number \_\_\_\_\_

Unit Dimensions \_\_\_\_\_

Unit Description \_\_\_\_\_

Owner's Name \_\_\_\_\_ Date Purchased \_\_\_/\_\_\_/\_\_\_

Owner's Address \_\_\_\_\_ Unit or Apt Number \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip Code \_\_\_\_\_

Telephone Number: (\_\_\_\_) \_\_\_\_\_ Fax Number: (\_\_\_\_) \_\_\_\_\_

Owner's Email Address: \_\_\_\_\_

Owner's Signature \_\_\_\_\_ Notary Signature \_\_\_\_\_

Notary Commission Expires: \_\_\_/\_\_\_/\_\_\_ Notary Stamp \_\_\_\_\_

**SERVICE REQUESTED**

Combination confirmation:      Yes    No  
\$10.00 charge for this service

Credit Card Information (Please circle one)    MasterCard    Visa

Expiration Date: \_\_\_/\_\_\_/\_\_\_    Card Number: \_\_\_\_\_

Credit Card Identification Number (Located on back of card, last 3 digits on signature strip) \_\_\_\_\_



# FIELD & STREAM™

1871

## Limited Lifetime Guarantee

If your Field & Stream Safe suffers damage due to theft or fire at any time while still owned by the original owner, Stack-On will either repair or replace (at Stack-On's discretion) your safe free of charge. If Stack-On chooses to repair the safe, such work may be performed by a local technician approved by Stack-On. Depending on the extent of the damage, Stack-On may require the safe be returned to the factory for repair; if the safe is to be returned, Stack-On will pay the freight to the factory as well as the return freight. If the safe is replaced, Stack-On will pay the freight.

This guarantee does not cover labor costs for removal or installation of the safe and its contents. Any repair, dismantling, or tampering undertaken without the prior written approval or direction of Stack-On will nullify this guarantee.

## Five Year Limited Warranty - Safes

Field & Stream Safes are warranted to be free from defects in materials and workmanship for a period of five (5) years from the date of original purchase by a consumer. This warranty extends to the initial consumer only.

If you believe there is a defect in material or workmanship in your Field & Stream safe during the five-year warranty period, please contact Stack-On's customer service department by regular mail or email at the address listed below. If Stack-On is properly notified during the Five-year warranty period and, after inspection confirms there is a defect, Stack-On will, at its sole option, provide repair parts, or exchange the product at no charge, or refund the purchase price of the product.

THIS WARRANTY DOES NOT COVER DAMAGE DUE TO ABUSE, MISUSE, NORMAL WEAR, EXCESSIVE WEAR AND TEAR CAUSED BY OWNERS NEGLIGENCE, INCLUDING FAILURE TO PERFORM ROUTINE MAINTENANCE, ACCIDENTS, MALFUNCTIONS CAUSED BY UNAUTHORIZED ALTERATIONS, IMPROPER INSTALLATION, USE OF UNAUTHORIZED PARTS OR ATTACHMENTS, LOST PARTS OR IF USED FOR COMMERCIAL OR RENTAL PURPOSES AND ACTS OF NATURE.

THIS LIMITED WARRANTY DOES NOT COVER ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OF ANY KIND, INCLUDING TRANSPORTATION TO GET WARRANTY SERVICE, LOSS OF TIME, AND LOSS OF USE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

Please send your claim pursuant to the above guarantee or warranty in writing by regular mail or email to:

Stack-On Products Company  
1360 North Old Rand Road  
Wauconda, IL 60084  
customerservice@stack-on.com

Please include in your correspondence:

1. Your name and address,
2. Description of warranty claim, fire, or theft
3. The serial number off of the safe
4. A copy of the report from the fire department, police, or insurance company within 30 days of damage
5. Proof of Purchase information of the safe

THE MANUFACTURERS, RETAILERS AND BRAND LICENSE OWNER, TOGETHER WITH THEIR DIRECTORS, OFFICERS, SHAREHOLDERS, AND EMPLOYEES WILL NOT, UNDER ANY CIRCUMSTANCES, BE LIABLE TO THE INITIAL CONSUMER FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, EXEMPLARY, OR PUNITIVE DAMAGES ARISING OUT OF THE PURCHASE OR USE OF THIS PRODUCT. IN NO EVENT SHALL THE OBLIGATION UNDER THIS WARRANTY OR GUARANTEE EXCEED THE PRICE OF OF THE PRODUCT.

**This product is not designed for the storage of computer disks, CDs, DVDs, audio/visual matter, photographs, or negatives.**